




zPix-27

**ZyPix - 2.7K Ultra HD
Head Mounted WiFi Vlog Camera**

一、 Specifications


Model	S110	Image resolution	12M/10M/8M/5M/3M/2M/1.3M/1M
DSP	GPCV1167	Image format	JPG
Sensor	GC2083	White balance	Auto
Display	0.96" ,IPS, 64×128	Exposure	Auto
Video resolution	2.7K 30fps/1080p 30fps/720p 30fps	ISO	Auto
Loop time	1min/2min/3min/5min	Data Transfer	Type-C 5pin USB
Video format	MP4	Horn	Support
Compressure format	H.264	WIFI APP	Roadcam
Angle of lens	110 degree	Working voltage	DC 5V 1A
Audio	Support	Working currency	180mA
MIC	Support	Charging currency	200mA
Memory	MAX 128G	USB	USB-Disk
Image	Support	Battery	250mAh

二、 Buttons




① Take out the device and frame, then place them in the front/side position.

② While clipped it, the camera is facing forward, the display is facing outward.



③ Clipped onto the glasses.

Note: Because there are too many different glasses in the market, this device can only fit about 70%, so in order to meet the needs of most customers, the company ships standard frames.



④ The standard for installation, please adjust the front and rear positions to get the best video/photo effect.

Power button

- 1, Press and hold for 2s to turn on/off.
- 2, In the working condition, click it to confirm.
- 3, In the resetting condition, click it to go down.

Menu

- 1, In the condition of standby, click it to confirm.
- 2, Press and hold it for 2s to record audio.

WIFI

- 1, Press and hold it for 2s to turn on/off WiFi.
- 2, In the condition of shoot video, click it to lock file.
- 3, In the menu, press and hold it to quit.
- 4, In the condition of standby, click it to switch between conditions, shoot image/video/replay. The power button will be confirmation button. Press and hold the button, WiFi to quit.

Reset/Mic: Click the reset hole to turn off audio.


WIFI APP:

1. Press and hold the button for 2s to turn on wifi.
2. In the WLAN of smartphone to find the WiFi name, S110** and connect it.

3. Download and open the APP, Roadcam to connect to camera.

4. WIFI: S110-*****
Password: 12345678, to connect.

QR for APP



Menu for video

Video resolution	2.7K/1080P/720P
Image resolution	1M/1.3M/2M/3M/5M/8M/10M/12M
timelaps	off/1s/2s/5s/10s/30s/60s
Loop time	off/1min/2min/3min/5min
Audio	off/on
Date/time	Off/Confirm/Save:Press and Hold the button, Up/Click Up/Down to reset.
Auto Turn off	Off/1min/3min
Screen saver	Off/1min/3min
Language	English, French, German, Chinese, simple Chinese, Italian, Spanish, Korean.
Frequency	50Hz, 60Hz
Format	Cancel, Confirm
Factory Default	Cancel, Confirm
Software version	AT-Year Month Day

Notice

1. Please use high speed micro SD card, it should be C10 or higher one.
2. Once you turn off the loop recording, the camera will not work if the memory is full.
3. The image is not clear. Please clean the lens.
4. The video quality it shoots is not stable. The video quality affected by light/angle.
5. Stuck: Press the reset hole to reset it.
6. Please do not use it in humidity place such as Sauna room/Hot spring room/high temperature, please do not disassemble the camera.